



# MANUAL DE INSTRUÇÕES

[www.lpmaquinas.com.br](http://www.lpmaquinas.com.br)

Leia o manual de instruções

LP Máquinas  
01/01/2018



# MANUAL DE INSTRUÇÃO

Thank you for using our products. For the safe of use of this new product, before operating this unit, please read these instructions completely and save manual for future use. Please do not attempt to disassemble or modified the machine!

## SCHEMATIC DIAGRAM



1. Defoaming Pressure
2. Laminating Pressure
3. Vacuum pressure
4. Touch system
5. Laminating Chamber
6. Bubble remove tank
7. OCA Laminating Pressure Regulator
8. LCD Laminating Pressure Regulator
9. Power Switch
10. Power

## PARAMETER

SUPPLY:	AC220V/AC110V
POWER:	800W
SIZE:	580*520*480mm
WEIGHT:	57kg

Here is laminating machine, no need connect outside compressor and pump, left is laminating part and right is remove bubble. Laminating is suit for hot-selling Samsung curved screen laminating and other digitizer laminating. It is also suitable for directly facing the screen.

Laminating operation steps.

1. Charge plug first, open power button
2. Control system start, press setting, laminating setting.
3. Laminating time 50 second, delay vacuum time 15 second, laminating temp 40.
4. Confirm, then remove bubble setting, remove bubble time 15-20 minutes, remove bubble temp 40.
5. Click confirm, then return, return to front page, click laminating and start then airbag start work
6. Laminating table automatic take out, put professional curved screen mould in laminating are.
7. For OCA curved LCD mould, click the laminating model, and get the LCD.
8. Put it on curved LCD mould, click the laminating model, and get the LCD.
9. When setting laminating time up, you can take out the tray, and get LCD.
10. When you film OCA on glass, you can use the OCA model, and if you laminate LCD, you should use the LCD model, the model can be changed on the LCD display.

### **Bubble removes operation steps:**

1. Press return, return to first page and press remove bubble, start.
2. When arrive setting remove bubble time, automatic exhaust, open door, take out screen, remove bubble finish

Obrigado por usar nossos produtos. Para a segurança do uso deste novo produto, antes de operar esta máquina, leia estas instruções completamente e guarde o manual para uso futuro. Por favor, não tente desmontar ou modificar a máquina!

### Diagrama Esquemático da Máquina



1. Pressão anti-espuma
2. Pressão de Laminação
3. pressão a vácuo
4. Tela Touch
5. Câmara de Laminação
6. Tanque removedor de bolha
7. Regulador de Pressão de Laminação OCA
8. Regulador de pressão de laminação LCD
9. Interruptor de Potência
10. Ligar

### Especificações Técnicas

VOLTAGEM:	AC220V/AC110V
POTÊNCIA:	800W
TAMANHO:	580*520*480mm
PESO:	57kg

Aqui está á maquinas de Laminar, não há necessidade de ligar um compressor externo ou bomba, a esquerda está laminando e parte direita o remover de bolha. Laminação é termo usado para laminar. Tela Samsung curva também pode ser usado para laminação. Também é adequado para trabalhar diretamente na tela.

Etapas da operação de laminação.

1. Plugue o cabo de energia primeiro, Aperto o botão Ligar
2. Início do sistema de controle, configuração de impressão, configuração de laminação.
3. Tempo de laminação de 50 segundos, atraso no tempo de vácuo de 15 segundos, temperatura de laminação 40.
4. Confirme, depois remova o ajuste da bolha, remova o tempo de bolha 15-20 minutos, remova a temp. Da bolha 40.
5. Clique em confirmar, em seguida, retornar, retornar à primeira página, clique em laminação e começar então o trabalho de partida do Airbag
6. A tabela de laminação automática remove, por molde profissional curvado da tela na laminação.
7. Para o molde de LCD curvo OCA, clique no modelo de laminação no painel do LCD.
8. Coloque-o no molde LCD curvo clique no modelo de laminação e obtenha o LCD.
9. Ao ajustar o tempo de laminação, você pode retirar a bandeja e obter o LCD.
10. Quando você filma OCA em vidro, você pode usar a modelo OCA, e se você laminar LCD, você deve usar o modelo LCD, o modelo pode ser alterado no visor LCD.

### **Bolha remove as etapas de operação:**

1. Pressione a tecla retorno, retorne à primeira página e pressione remover bolha, iniciar.
2. Quando chegar configuração remover tempo bolha, escape automático, porta aberta, retire a tela, retire o acabamento da bolha.